



- There is a "yellow / blue" line coupler in black / gray coupler both. Please connection work so as not to confuse great care to keep connected to each, or because there is an interrupt.
- The purple line is the service output line. The ENIGMA will output 5V each crank rotation. Most commercially available digital tachometers are supported. Exact values will be displayed if these cables are connected. They are useful to various applications. Do not short-circuit by taping when there is no need.
- The limiter has not been canceled after the wiring connection is complete. It can be easily canceled by communicating with the Enigma operating software on a smartphone or PC.
- The Enigma operating software can be downloaded free from our website.

<http://www.dilts-japan.com>

It has been produced in PCX125-JF28 only. Do not install the PCX125-JF56,PCX150 and another model. It may cause trouble if you install it because it is manufactured based on the basic data of the normal injection ECU of PCX125.